

WypAll® WetTask™

Customizable Wet Wiping System



Activation in 3 easy steps



STEP 1:

- Remove lid from WetTask™ container.
- Remove roll of dry wipes from packaging and insert roll into container.



STEP 2:

- Pour approximately the following amounts of diluted or ready-to-use chemical solution of choice into a measuring container:

Saturation Guide

WetTask™ System Base Sheet	SKU #	Wipes/Roll	Wipes Size	Pour Amount
Meltblown <i>CriticalClean™</i>	77320	55	12" x 6"	12 oz.
	06411	140	12" x 6"	32 oz.
	06471	140	12" x 6"	32 oz.
Spunlace <i>PowerClean™</i>	06211	140	12" x 6"	28 oz.
	53850	250	5.8" x 9"	40 oz.
Hydroknit® <i>PowerClean™</i>	06001	95	12" x 6"	42 oz.
	06006	275	9" x 15"	224 oz.

Use this amount of liquid as a guide, depending on your desired level of saturation. To verify appropriate concentration of actives in disinfectants and/or sanitizers, use of test strips is typically advised and made available by your chemical supplier.

- Slowly pour chemical liquid over the top of the roll in the WetTask™ System bucket.

NOTE: When using chemicals, it is important to review the safety data sheet of your chemical of choice and adhere to any/all PPE requirements.



STEP 3:

- Thread the center wipe from the center of the roll through the lid opening and fasten the lid.
- Let the wipes roll soak for 5 minutes before use to ensure the liquid fully saturates wipes.

Remember to label your WetTask™ container with the chemical manufacturer's secondary label (i.e., same as you would on your spray bottle or bucket).

Visit our website at www.KCProfessional.com
OR contact us at 800-255-6401

MORE INFO:

